




Инструкция


AMV 25 SU, AMV 25 SD




AMV 25 SU / SD
+ VRB 3, VRG 3




AMV 25 SU / SD
+ VF 2/3, VL 2/3





AMV 25 SU / SD
+ VFS 2, VEFS 2







1



2



3



Ручное управление

AMV 25 SD

AMV 25 SU

