




**Installation Guide** 

## **Service Kit OBC 80 series**

BHO (9 terminals)








**Content - Service Kit 057H7224** 


	057H7010
	057H7011
	057H7012
	057H7087
000	057H7071
	057H7072
	-

© Danfoss | 2019.03 VI.HN.A2.00 | 1












## **OBC 81 A**





**OBC 82** 






**OBC 82 A** 







**OBC 84** 



OBC 85B





## Danfoss A/S

 $Heating \ Segment \cdot heating. dan foss.com \cdot +45\ 7488\ 2222 \cdot E-Mail: heating@dan foss.com$ 

▶ 4

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and all Danfoss logotypes are trademarks of Danfoss A/S. All rights reserved.

\_\_\_\_\_\_\_V1

]