



38 784




38 804




38 808




38 857




38 784




38 804






38 808




38 857



Bitte diese Anleitung an den Benutzer der Armatur weitergeben!
Please pass these instructions on to the end user of the fitting!
S.v.p remettre cette instruction à l'utilisateur de la robinetterie!




3




bar

	1	2	3	4	5	6
	2,5l	3l	4l	4,5l	5,5l	6l
	1,5l	2l	3l	3,5l	4l	4,5l
	1l	1,5l	2l	2,5l	3l	3,5l
	-	-	1l	1,5l	1,8l	2l


4



5




6




X =
 8 mm (38 784)
 11 mm (38 804)
 31 mm (38 808)
 9 mm (38 857)


7



8



9



10

38 784 SD0

