avrora-arm.ru +7 (495) 956-62-18





Counterfeit & Danfoss products (077B thermostats)

Operational guide to identify counterfeit and originals

Birthe Hansen, Global Quality Manager, September 2019



Danfoss 077B



Danfoss 077B




Danfoss 077B




Danfoss use many different code no.


Danfoss logo

Name of material used in Danfoss 077B





Name of material used in Danfoss 077B




Example of counterfeit

Sold under Danfoss brand and with UL on shell (body) and plastic tube.

Shell (body)

Danfoss do not use turned parts as spindle and connector.

Danfoss do not use text on plastic coated tube.



Original approvals for Danfoss 077B






Original Danfoss 077B thermostat




Imitation of approvals for Danfoss 077B












Danfoss closing of bottom / capillary tube included soldering



Imitation closing of bottom / capillary tube exclude soldering



Danfoss Spindle / Connector (casting parts)



Imitation Spindle / Connector (turned parts)



Danfoss Danfoss logo on Shell



Imitation With and without Danfoss logo on Shell




Turned parts

Copy of Danfoss thermostat compared with Danfoss original





Danfoss Closing of sensor





Imitation Closing of sensor





Danfoss Stamping / laser on cover plate (can be in black, grey or brown)




Imitation Stamping on cover plate (many variants seen)




Copper coated spring



Danfoss | Main arm with torx screw Spring steel




Imitation
Main arm
with cross screw Copper coated iron



Danfoss


Danfoss logo on Contact house, contact house can be grey, brown (nature) or black.




Imitation

Without Danfoss logo on Contact house (Both number and letter not seen on imitations)






Danfoss Differencial-screw in contact-house




Imitation Differencial-screw in contact-house



Danfoss

Contact system (ID no. 3 and 6 for connection is placed different)



Imitation Contact system



avrora-arm.ru +7 (495) 956-62-18